



**ArmourTone**<sup>®</sup>  
ABUSE RESISTANT FINISHES

# ArmourTone Fine<sup>™</sup>

## Description

ArmourTone Fine is a semi-smooth, high performance, acrylic polymer based, integrally colored texture coating.

## Uses

ArmourTone Fine may be used for interior applications over properly prepared substrates. Creates looks ranging from traditional knockdown, splatter and orange peel textures to smooth troweled finishes. May be used over a basecoat of ArmourFill, ArmourPrime, or in a two coat application.

## Color

White  
24 Standard Colors

## Coverage

500-700 sq. feet per 5 gallon pail (one coat) depending on texture (orange peel, knockdown, etc.).

## Shelf Life

Minimum of one year when stored in a cool dry location out of direct sunlight and kept from freezing.

## Project Conditions

Substrate must be clean, dry, sound and free of contaminants such as dust, oil, mildew and efflorescence. Ambient conditions, substrate and the product itself must be at a minimum of 45°F during application and at least 48 hours following.

## Mixing

Thoroughly mix with a paddle mixer to a homogeneous consistency at low rpm. In a 5 gallon container, up to 16 ounces of clean, potable water may be added to adjust viscosity. Close container when not in use.

## Substrate Preparation

### New Drywall

Treat all joints, fasteners & accessories with the industry standard joint treatment system for attaining a Level 3 finish as outlined in Gypsum Association publication GA-214, "Recommended Levels of Gypsum Board Finish".

### Masonry and Textured Surfaces

Concrete and plaster surfaces should be thoroughly cured before application. Poured concrete surfaces should cure for at least 28 days before finishing. Cement and gypsum plaster basecoats should cure for at least 7 days before finishing. Remove all form release agents and efflorescence and grind down form lines or other irregularities which protrude from the plane of the substrate. Using ArmourTone Level Coat or an approved leveler.

## Application

- Apply a basecoat of ArmourFill, AT Prime or ArmourTone Fine.
- Spray ArmourTone Fine using typical drywall texturing equipment. For small areas a hopper and compressor may be used. For large scale projects a texture pump is preferable. Adjust gun orifice size and pressure settings to achieve the desired texture.
- Use stainless steel plaster trowels or drywall knives to knock down the finish to achieve the desired final appearance.
- AT Stain may be sprayed while the finish is still wet and troweled randomly into the finish to create a mottled appearance.

**Note:** Consult manufacturer for expanded application instructions including pressure settings and specific equipment recommendations.

## Drying Time

The finish will dry to the touch within 3-4 hours over most substrates and ambient conditions. Avoid heavy traffic or cleaning for 48 hours after application. Protect from rain for a minimum of 24 hours per coat. Surface absorption, temperature and humidity affect drying time.

## Clean Up

Clean tools and equipment with water immediately after use.

## First Aid

SKIN CONTACT: Wash thoroughly with soap & water. EYE CONTACT: Flush immediately with water for 10-15 minutes and contact a physician.

## Spills

Scrape up and wash with water immediately. If material has set, scrape material with appropriate tools and clean with citric acid.

## Disposal

Dispose of in accordance with local, state or federal regulations.

## Warning

KEEP OUT OF REACH OF CHILDREN. NOT FOR INTERNAL CONSUMPTION, FOR INDUSTRIAL USE ONLY.

**65 lbs. • 29.48 kg.**

**ArmourTone Finishes LLC**

**12600 Osito Court NE • Albuquerque, NM 87111 • (505) 400-7166**